

MAXISWITCH 20A 4 WAY POWER BOARD


Congratulations ! You now have the best quality power board money can buy. Before you connect any part of the system, please make sure you get the most from the unit by taking a minute to read this important information.

Safety Advice

- This unit must be installed by a qualified electrician.
- This unit must be protected by a suitable fuse.
- Before doing anything with the unit, make sure that the power supply is turned off.
- Keep away from children, pets and water.
- This product is intended for switching electrical products with a total load not exceeding 20A.
- Never use more than 20A of HID (High Intensity Discharge) lighting with this unit.
- Never tamper with the unit as there are no user serviceable parts inside and this will void the guarantee.
- Before disconnecting the unit, switch the power off to it and leave for at least 3 minutes. This will allow any connected appliances to safely discharge.

Installation

After successful installation by a qualified electrician, please set the current time on the timer by rotating the minute hand until the arrow head aligns with the correct time. To set ON/OFF times, move all tappets between ON and OFF times required to outer position. i.e. to set ON at 7:30am and OFF at 10:30am, move all tappets between 7:30 and 10:30 to outer position (See Fig 1). Set any other ON/OFF periods required in a similar manner. The manual override switch on the timer has 3 settings. The position marked 'T' indicates that the unit will be permanently on, regardless of tappet positions. The position marked 'O' indicates that the unit will be permanently off regardless of tappet positions. Position \odot indicates that the timer will switch on/off according to the tappet positions you have selected.



Please note that the maximum load that can be drawn across all sockets is 20A and that the maximum power that can be drawn from any given socket is 13A. Refer to the respective appliance's instructions for the number of amps that they draw. Plug your appliances into the control unit's sockets making sure you do not overload them.

Troubleshooting

If you suspect that the power board is at fault, test it by plugging in a known working appliance.

Guarantee & Liability

In the unlikely event that you find fault with this product, please contact your supplier. All Maxibright Control Units carry a two year guarantee (terms & conditions apply), excluding faulty fuses and tampering. The manufacturer shall not be responsible for any damage caused by operation of the unit, be it incidental or consequential; or of any type; including, without limitation, damage or injury, caused to other products, machinery, or buildings. Nor will responsibility be accepted for loss of time or profit, loss of finished product, or for any inconvenience caused in any way whatsoever.